


Step 3


Put the fixture onto the pole then tight the screws ,once the fixture is properly fastened, you are now ready to enjoy the light



III . Installation instruction (normally fit for 3" round pole , 2 3/8" insert is available)

Step 1

Switch CCT and Power button ,select CCT and wattage needed for project



UFO LED Post Top Light Instruction Manual



I. Application :

Community Parking area ,plaza ,roadway , pathway , square , general site & area lighting etc

II . Features

- (1)Whole set of optics lens for lighting distribution , Lighting efficiency up to 120LM/W-130LM/W.
- (2)Space between the modules , it brings excellent air convection , heat can be sent off immediately ,keeping led working under low temperature
- (3)AC120-277V / 347V / 480V Input Voltage.
- (4)Unique and Beautiful appearance for UFO Round Shape.
- (5)Photocell /Motion Sensor available
- (6) CCT and wattage filed selectable

VI. Installation Notes:

- Cut off the power and make sure the wall can burden the weight of the lamp.
- Before install the lamp, ensure the lamp wiring correctly, don't let the lamp's dropping down.
- Do not use the lamp in the area where have aggressive gas.
- Do not cover anything on the lamp which is harmful for heat sink.
- Products faults caused by separating , remodeling or incorrectly construction are not in the quality warranty range .

Step 2

Connect the ACL and the ACN from the driver to the conduit with the AC Power Supply cords

White: Neutral
Black: Live
Yellow Green: Ground

